


H19H

Wi-Fi CONNECTION

2.4GHZ 6-AXIS GYRO

NAMES OF PARTS REMOTE CONTROL 遥控器各部位名称



- ① 电源指示灯
POWER INDICATOR
- ② 手机支架 (仅WIFI版有)
MOBILE PHONE HOLDER
(ONLY FOR WIFI VERSION)
- ③ 短按一键启动长按关灯
SINGLE PRESS IS ONEKEY START,
A LONG PRESS IS OFF LIGHTS
- ④ 短按拍照, 长按录像
(该按键不支持WiFi版本)
SINGLE PRESS CAMERA, A LONG
PRESS VIDEO (THIS BUTTOON IS
NOT SUPPORT WIFI VERSION)
- ⑤ 短按速度控制, 长按一键返航
SINGLE PRESS IS SPEED CONVERSION,
A LONG PRESS IS A KEY RETURN
- ⑥ 短按翻滚待命, 长按无头模式
SINGLE PRESS IS 3D EVERSION,
A LONG PRESS IS HEADLESS MODE
- ⑦ 左操纵杆 (上升/下降/左转/右转)
LEFT CONTROL STICK (ASCEND/
DESCEND/TURN LEFT/TURN RIGHT)
- ⑧ 右操纵杆 (前进/后退/左侧飞/右侧飞)
RIGHT CONTROL STICK (FORWARD/BACKWARD/
LEFT AND RIGHT SIDE FLYING)
- ⑨ 前进/后退微调
FORWARD AND BACKWARD FINE-TUNING
- ⑩ 左转/右转微调
LEFT AND RIGHT TURN FINE-TUNING
- ⑪ 左侧飞/右侧飞微调
LEFT AND RIGHT FLY FINE-TUNING
- ⑫ 电源开关
POWER SWITCH

WIFI CONNECTION WIFI连接

1. Install the camera into the drone, then plug the power cord into the WIFI socket of drone.
把WIFI摄像头安装到飞行器上面, 再把电源线插到飞行器的WIFI插口。
2. Scan the QR code with a mobile phone to download the APP "WIFI UFO". As shown in figure 1, it supports GOOGLE, PLAY, and IOS.
用手机扫描二维码并下载安装控制软件《WIFI-UFO》, 支持GOOGLE PLAY, 360和IOS, 如图1所示。



Google play



360手机助手



ios



WIFI-UFO

Figure1

3. As shown in figure 2, please connect WIFI "WIFIUFO-7216cc" with your phone.
用手机连接WIFI《WIFIUFO-7216cc》, 如图2所示。
4. As shown in figure 3, open APP "WIFI-UFO" in the phone. Then click "Play" to enter standard mode control interface, as shown in figure 4.
打开手机里的《WIFI-UFO》APP软件, 如图3所示。
点击 "Play" 进入标准模式控制界面, 如图4所示。




Figure2



Figure3



Figure4

5. When the video connection has succeed, you can watch the images that relay from the WIFI camera.
视频链接成功, 可以通过手机屏看到wifi摄像头回传的画面。

THE LCONS IN THE PLAY PAGE 播放界面各图标含义

